

Textile Jet Tx3-1600

Mimaki

-Quick reference-
For setting 1 liter ink pack

Thank you for purchasing MIMAKI Tx3-1600 color inkjet plotter for textile and 1 liter ink pack.
Please read this manual before using 1 liter ink pack.

Contents of 1 liter ink pack Set :



1 liter ink pack



Spout holder

STEPS:

1. Flip the spout holder and 1 liter Ink pack.

The label side of SPC No turns over.




- Do not touch the IC tip part to avoid breaking.

2. Insert the spout into the central hole of the spout holder, and then push it down with a finger.




- Push the spout down until it clicks.



Spout

3. Turn the both face up to confirm that there is no gap between spout and the central hole.




Improper setting (gap)



- In case the spout is not set properly, it may not be able to supply inks normally and also may cause break the device.

4. Set the holder and ink pack to the ink tray.

Pull the ink tray out from the inkstation, and then set the holder and ink pack to the ink tray. In case setting, turn the IC tip and label face up.



5. Insert the ink tray into the inkstation.

